



StraightCut

Included Parts


(Some parts pre-assembled)




Straight Handle
TC-09-1550



45 mm Blade
TC-08-1102




Guide Pin
TC-09-1377



Pin
TC-09-1378




Ruler Guide
TC-05-1258




Configurations

Can be set up with or without the ruler guide.




Pictured: With Ruler Guide




Pictured: Without Ruler Guide

Changing the Blade


- 1 Push out the **release** to drop the **pin**.




OR



- 2 Carefully slide the **blade** off the **blade guard**.



- 3 Position the handle over the **new, sharp blade**. The magnet will pick it up.



- 4 Press the **pin** into the handle until it clicks in place.

